


MS 1000 Tripod Case and Assembly Photographs



The sonar head is delivered in the protection cage when it is purchased at the same time as the tripod. Rinse the cage, head, and legs with clean water after use in salt water, let dry and return to the shipping case.



The led weight is supplied to minimize the sonar head from swaying in a current; it does not have to be used if the tripod and head is stable when deployed.

